# **TCF102**



# WALL MOUNTED BOILER UNIT



### **Experimental capabilities**

- Identification of the components of a wall-mounted boiler installation
- Commissioning of a gas boiler
- Setting a wall-mounted boiler (combustion, regulation, efficiency, requires the optional combustion analyzer)
- Maintenance of a wall-mounted boiler
- Thermal study of a wall-mounted boiler installation (balance, production of heating and production DHW)
- Hydraulic study of a wall-mounted boiler installation (mixing law, flows, temperatures, pressures..)

# TCF102



## **Operating principle**

The TCF102 bench allows the study of a gas wall-mounted boiler. The installation comprises a circuiting of heating and DHW production that is used on a sink located next to the boiler.

The hydraulic circuit includes all the components of a conventional domestic heating circuit.

Students will begin by identifying the components of the circuit and draw the hydraulic diagram. Then they will proceed with the commissioning and system setting and will end up by analyzing the operation by recording the parameters (temperature, flow rate, pressure).

The bench is available in 4 different versions according to the type of boiler and the associated production (DHW and heating) .The dissipation can be achieved by various optional benches.

The robust design of this equipment makes it perfectly suited for use in schools.

Its anodized aluminum frame with legs gives it great strength as well as great flexibility of integration into your premises. The manufacturing of this equipment meets the European machine directive

This equipment can be used alone or with other compatible equipments in our range (see last section of this document).

### Illustrations



1. Wall-mounted boiler:

Version 1: Power around 24KW , DHW micro accumulated, 1 direct heating circuit

Version 2: Power around 24KW , DHW micro accumulated, 1 direct heating circuit, condensing boiler

Version 3: Power around 24KW, DHW micro accumulated, 1 controlled heating circuit, condensing boiler

Version 4: Power around 24 KW, DHW by tank, 1 controlled heating circuit, condensing boiler

2. Gas supply line composed of standard elements:

- Pressure manometer 0-60mbars
- Volumetric gas meter

- Stop valves before and after meter

#### **Services required**

- Power supply: 230 Vac 50 Hz 6 A
- Power supply type: 1 phase(s) + Neutral + Earth.
- Water supply: 10 L/min 2 bars
- Water disposal: at ground level
- Evacuation of fumes: suction cup diameter 60/100mm
- Supply in fuel: Natural gas (butane possible on request)
- Dimensions: (LxWxH mm): 2000 x 800 x 1950
- weight (Kg): 170

Note : if the equipment installation is operated by our staff, all supplies and exhaust connections required must stand at less than 2m from the machine

#### **Technical specifications**

3. Use of Domestic Hot Water (DHW) composed of:

- A stainless steel sink with plumbing kit
- A mixer tap

- Instrumentation: flowmeter, thermometer and pressure gauge for each circuit (hot and cold water)

4. The unit can have two types of heating circuit :

- Direct circuit comprising: a flowmeter, two thermometers, a balancing valve on the return, a differential valve, two quick connectors.

- Regulated circuit comprising:a primary circuit, a bottle decoupling, a three-way valve, a circulating pump, 2 flowmeters, 4 thermometers, 2 balancing valves on the return, a differential valve, two quick connectors.

- Version 1: 1 direct heating circuit
- Version 2: 1 direct heating circuit

Version 3: 1 controlled heating circuit

Version 4: 1 controlled heating circuit

5. Power electrical box including a main switch, circuit breakers, a white indicator light for voltage presence and commissioning button.

6. Water supply line comprising two stop valves, a meter, a filter, an anti-pollution check valve.

#### **Documentation**

- User's manual
- Pedagogical manual
- Technical documentation of the components
- Lab exercises
- Wiring diagram
- Hydraulic diagram
- Certificate of conformity CE

DIDATEC- Zone d'activité du parc - 42490 FRAISSES- FRANCE Tél. +33(0)4.77.10.10.10 - Fax+33(0)4.77.61.56.49 - www.didatec-technologie.com email : service\_commercial@didatec-technologie.com Reproduction interdite / copy prohibited- Copyright DIDATEC juin-18- page 2 Dans le cadre de l'amélioration permanente de nos produits, ce descriptif technique est susceptible d'être modifié sans préavis As part of the continuous improvement of our products, this technical specification may be modified without previous notifying Illustrations not contractuelles / Illustrations not contractual version : FT-TCF102-STD-D

# **TCF102**

DIDATEC

#### Options

Portable combustion analyzer

### Additional compatible equipments

- Radiators bench
- underfloor heating bench
- Radiators bench with balancing
- Balancing briefcase
- Fan heater

• Ref : KIG100

Additional compatible equipments		
er	•	Rof · AER033
	•	
	•	Ref : TCF120
ench	•	Ref : TCF121
n balancing	•	Ref : TCF122
	•	Ref TCF123

Ref : TCF123
Ref : TCF124